


ROBO-8710VLA

PICMG SBC, Based on Socket 478 Pentium® 4 Processor with DDR SDRAM, AGP 4X VGA, Fast Ethernet and Audio



Feature

- Reliable design for higher speed Pentium®4 processor
- Intel® 845 chipset, backed up by Intel EID's long product life support
- High speed mainstream DDR SDRAM memory
- ECC function for data sensitive application
- ATI 3D graphics controller supports versatile interfaces for most of image process transaction terminals and panel display system applications
- High integration input/output function, such as high driving digital I/O and SMBus
- Standard features for embedded system, like H/W monitoring, WDT, SSD and Wake-on-LAN
- Additional external power connector for stand alone operation for rugged embedded system design

Specifications

CPU	mPGA478 socket Pentium®4 processor up to 2.0GHz
Processor System Bus	400 MHz
Chipset	- Intel® 845, Intel® MCH and ICH2 - ATI Mobility M6 3D graphics controller
Memory	- Two 184-pin DIMM sockets - 2.5V 200/266 MHz DDR SDRAM up to 2GB - ECC support
BIOS	- AMI or Award BIOS with PC'98 support - 4Mb flash ROM for easy upgrading
On-Board I/O	- Support for two enhanced IDE channels with Ultra DMA/33/66/100 - Support floppy disk interface up to two drivers - Two serial ports, one parallel port, one IrDA and three USB ports - 8 high driving GPIO (4 GPI, 4GPO)
Watchdog Timer	Programmable via software from 0.5 sec to 254.5 min
PS/2 K/B & Mouse	- One mini-DIN 6-pin connectors for keyboard and mouse - One 5-pin header connector for external keyboard connection
Power requirements	TBD, one external power connector for stand alone operation
Operating temperature	0 to 55°C
Storage temperature	-20 to +75°C
Relative Humidity	5% to 90%, non-condensing
Dimension	338.5(L) x122(W) mm; 13.33"x(L) x 4.8"(W)

Additional Functionality

VGA/Panel	- ATI Mobility M6 Graphics controller - 16MB 200MHz DDR SDRAM display cache - TMDS/LVDS Interface support - Dual View support - TV-out
Ethernet	- One ICH2 Integrated MAC controller with external 10/100MB phy - One RJ-45 phone jack - Two LED indicators for LAN access and link status
Audio	AC-97 2.0 audio
Solide State Disk	DOC socket for up to 288MB
SCSI	Adaptec AIC 7892 single channel Ultra 160 SCSI controller (optional)
System Hardware Monitor	CPU voltage, temperature and fan monitoring
ISA64 Driving	64mA high driving capability for ISA-bus slot on backplane
ATX Power Control	ATX function with 4-pin header connect to backplane

Ordering Guide

ROBO-8710VLA

Socket 478 Pentium®4 processor based PICMG SBC with DDR SDRAM, AGP 4X VGA, fast Ethernet and audio

ROBO-8710VLA
Single Board Computer

User's Manual

P/N : B8980710 Version 1.0

Copyright © Portwell, Inc., 2002. All rights reserved.
All other brand names are registered trademarks of their respective owners.

Table of Contents

How to Use This Manual

Chapter 1. Introduction

1-1 Introduction.....	1-1
1-2 Check List	1-2
1-3 Product Specification	1-3
1-4 System Architecture	1-6

Chapter 2. Hardware Configuration Setting

2-1 Jumper Setting	2-1
2-2 Connector Allocation	2-3

Chapter 3. System Installation

3-1 Pentium 4 Processor	3-1
3-2 Main Memory	3-2
3-3 M-systems Flash Disk	3-3
3-4 Installing the Single Board Computer	3-4
3-4-1 Chipset Component Driver.....	3-4
3-4-2 ATI Mobility Radeon Graphic Integrated Chipset	3-5
3-4-3 On-board Fast Ethernet Controller	3-6
3-4-4 On-board AC-97 Audio Device	3-6
3-4-4 On-board 68-pin PCI connector.....	3-6
3-5 Clear CMOS Operation.....	3-7
3-6 WDT Function.....	3-7
3-7 SMBUS	3-9
3-8 Display Output	3-9
3-9 GPIO.....	3-10

Chapter 4. BIOS Setup Information

4-1 Entering Setup.....	4-1
4-2 Main Menu	4-2
4-3 Standard CMOS Setup Menu.....	4-3
4-4 IDE Adaptors Setup Menu	4-4
4-5 Advanced BIOS Features.....	4-6
4-6 Advanced Chipset Features	4-10
4-7 Integrated Peripherals.....	4-13
4-8 Power Management Setup	4-19
4-9 PnP/PCI Configuration Setup.....	4-23
4-10 PC Health Status.....	4-25
4-11 Frequency/Voltage Control	4-26
4-12 Default Menu	4-27

4-13 Supervisor/User Password Setting.....	4-27
4-14 Exiting Selection	4-28
4-15 POST Messages	4-29
4-16 BIOS POST Check Point List.....	4-34
4-17 BIOS Flash Utility	4-39

Chapter 5. ATX Power Setting

5-1 ATX Power Setting.....	5-1
----------------------------	-----

How to Use This Manual

The manual describes how to configure your ROBO-8710VLA system to meet various operating requirements. It is divided into five chapters, with each chapter addressing a basic concept and operation of Single Board Computer.

Chapter 1 : Introduction. presents what you have in the box and give you an overview of the product specifications and basic system architecture for this model of single board computer.

Chapter 2 : Hardware Configuration Setting. shows the definitions and locations of Jumpers and Connectors that you can easily configure your system.

Chapter 3 : System Installation. describes how to properly mount the CPU, main memory and M-systems flash disk to get a safe installation and provides a programming guide of Watch Dog Timer function.

Chapter 4 : BIOS Setup Information. specifies the meaning of each setup parameters, how to get advanced BIOS performance and update new BIOS. In addition, POST checkpoint list will give users some guidelines of trouble-shooting.

Chapter 5 : ATX Power Setting. provides you a few useful tips to quickly get this ROBO-8710VLA running with different power supply. As jumper configuration has been addressed in the earlier paragraphs, this section will basically focus on the ATX power setting.

The content of this manual and EC declaration document is subject to change without prior notice. These changes will be incorporated in new editions of the document. **Portwell** may make supplement or change in the products described in this document at any time.

Updates to this manual, technical clarification, and answers to frequently asked questions will be shown on the following web site :

<http://www.portwell.com.tw>

CHAPTER 1

1-1 Introduction

ROBO-8710VLA is built based on ATI-Mobility Radeon High performance graphic integrated chipset and Intel fast Ethernet controller that support Intel[®] high performance processor; Intel[®] 478-pin Pentium[®] 4 Processor.

This single board computer runs with Intel[®] Pentium[®] 4 processor, and supports DIMM up to 2GB DDR SDRAM maximum. The enhanced on-board PCI IDE interface can support 4 drives up to PIO mode 4 timing and Ultra DMA/33/66/100 synchronous mode feature. The on-board Super I/O Chipset integrates one floppy controller, two serial ports, one keyboard controller, hardware monitoring, one IrDA port and one parallel port. Besides, three USB (Universal Serial Bus) ports provide high-speed data communication between peripherals and PC.

Its proprietary PCI extension connector provides an easy way to add additional function like U160 SCSI or 2nd LAN device in minutes. The compact form factor with proprietary PCI connection interface makes it the best and flexible daughter board solution for adding more function in limited space.

The PICMG standard makes the ROBO-8710VLA works with the legacy ISA, ISA/PCI or multi-slots PCI-bus backplane. The on-board 32-pin DIP socket supports M-systems DiskOnChip 2000 product up to 512MB. The Watch-Dog Timer function can be used to restart you system whenever system goes abnormal. One 6-pin Mini-DIN connector (with Y-Cable) is provided to connect PS/2 Mouse and Keyboard. The on-board Flash ROM is used to make the BIOS update easier, ROM chip can be replaced quickly. All of these features make ROBO-8710VLA excellent in many applications and one of the best performing single board computer in the market.

1-2 Check List

The ROBO-8710VLA package should cover the following basic items with the Quick Installation Guide.

- ✓ One ROBO-8710VLA single board computer
- ✓ One Parallel port cable kit
- ✓ One serial port cable to support two interfaces
- ✓ One FDC cable
- ✓ One IDE cable
- ✓ One Y-Cable cable for PS/2 Keyboard and Mouse
- ✓ One 5-pin to 5-pin keyboard cable for backplane connection
- ✓ One 4-pin ATX power control cable for backplane connection
- ✓ One CD-Title to support ATI Mobility Radeon High performance graphic integrated chipset and Intel 82801BA MAC Fast Ethernet controller.
- ✓ CPU holder
- ✓ Multimedia cable

If any of these items is damaged or missing, please contact your vendor and keep all packing materials for future replacement and maintenance.

1-3 Product Specification

- ◆ **Main processor**
 - Intel® Pentium® 4 processors
 - PSB: 400MHz

- ◆ **BIOS**
 - Award system BIOS with 512KB Flash ROM with easy upgrade function ACPI, DMI, Green function and Plug and Play Compatible

- ◆ **Main Memory**
 - Two DIMM sockets support non-buffered 200/266 DDR-SDRAM up to 2GB. ROBO-8710VLA supports ECC function without buffer or register.

- ◆ **L2 Cache Memory**
 - 512KB in Pentium-IV processor

- ◆ **Chipset**
 - Intel 82845 Chipset

- ◆ **Bus Interface**
 - Follow PICMG 1.0 Rev 2.0 standard (32-bit PCI and 16-bit ISA)
 - Fully complies with PCI Local Bus specification V2.1 (support 4 master PCI slots)

- ◆ **PCI IDE Interface**
 - Support two enhanced IDE ports up to four HDD devices with PIO mode 4 and Ultra DMA/33/66/100 mode transfer and Bus Master feature

- ◆ **Floppy Drive Interface**
 - Support one FDD port up to two floppy drives and 5-1/4"(360K, 1.2MB), 3-1/2" (720K, 1.2MB, 1.44MB, 2.88MB) diskette format and 3-mode FDD

- ◆ **Serial Ports**
 - Support two high-speed 16C550 compatible UARTs with 16-byte T/R FIFOs

- ◆ ● **IR Interface**
 - Support one 6-pin header for serial Standard Infrared wireless communication

- ◆ ● **Parallel Port**
 - Support one parallel port with SPP, EPP and ECP modes

- ◆ ● **USB Interface**
 - Support three USB (Universal Serial Bus) ports for high-speed I/O peripheral devices

- ◆ ● **PS/2 Mouse and Keyboard Interface**
 - Support one 6-pin Mini-DIN connector and one 5-pin shrouded connector for PS/2 mouse/keyboard connection through Y-Cable and backplane connection

- ◆ ● **ATX Power Control Interface**
 - One 4-pin header to support ATX power control with Modem Ring-On and Wake-On-LAN function

- ◆ ● **Auxiliary I/O Interfaces**
 - System reset switch, external speaker, Keyboard lock and HDD active LED

- ◆ ● **Real Time Clock/Calendar (RTC)**
 - Support Y2K Real Time Clock/calendar with battery backup for 7-year data retention

- ◆ ● **Watchdog Timer**
 - Support WDT function through software programming.

- ◆ ● **Disk-On-Chip (DOC) Feature**
 - Reserved one 32-pin socket for M-systems Flash Disk up to 512MB
 - DOS, Windows, Win95, NT (bootable) drivers and Utility supported

- ◆ ● **On-board VGA**
 - ATI-Mobility Radeon graphic controller works in combination with a 16MB DDR-SDRAM.

- ◆ ● **On-board Ethernet LAN**
 - Intel 82801 ICH2 integrated LAN controller to support RJ-45 connector.

- ◆ ● **On-board 68-pin PCI device connector**
 - Support one additional PCI device daughter board

- ◆ ● **High Driving Capability**
 - Support 64mA high driving capability for multi-slots ISA-bus

- ◆ ● **CPU Cooling Fan**
 - Support three 3-pin headers with wafer

- ◆ ● **System Monitoring Feature**
 - Monitor CPU and system temperature

- ◆ ● **Bracket**
 - Support one Mini-DIN, one-port USB, one Ethernet port with indicator and one CRT port

- ◆ ● **Physical and Environmental Requirements**
 - Outline Dimension (L X W): 338.5mm (13.33") X 122mm (4.8")
 - Power Requirements:
 - +12V (CPU) @2.7A
 - +12v (System) @0.6A
 - +5V @3.7A

 - **Test Configuration:**
 - CPU: Intel P4 1.8GHz/ 400MHz PSB, 512KB L2 Cache
 - Memory: DDR SDRAM 512MBx2
 - Primary Master IDE HDD: Seagate ST330620A
 - O.S.: Microsoft Windows 2000 + SP2
 - Test Program: 3D Mark 2001
Burning Test V2.2
 - Operating Temperature: 0°C ~ 60°C (32°F ~ 140°F)
 - Storage Temperature: -20°C ~ 80°C
 - Relative Humidity : 0% ~ 95%, non-condensing


1-4 System Architecture

The most up-to-date system architecture of ROBO-8710VLA includes two main Intel chips, Intel 845D chipset supports Pentium-4 processor, DDR-SDRAM, 2D/3D graphic display, and its 82801BA ICH2 supports PCI bus interface, APM, ACPI compliant power management, USB port, SMBus communication, and Ultra DMA/33/66/100 IDE Master, and it also provides a Fast Ethernet controller. W83627HF (I/O Controller) is responsible for PS/2 Keyboard/Mouse, UARTs, FDC, Hardware Monitor, Parallel, Watch Dog Timer and Infrared interface.

The special pin configuration of the CPU socket adopts the 478 pins in total. This new generation CPU provides better performance to many applications.

The PCI-to-ISA bridge supports a standard 16-bit ISA bus interface which is applied for all slower I/O operations. In ROBO-8710VLA, it supports DiskOnChip (DOC) for M-systems Flash disk.

There is one on-board PCI Fast Ethernet via RJ-45 Ports to support full functionality of ROBO-8710VLA AIO SBC (All-In-One Single Board Computer). The on-board 68-pin PCI connector supports additional daughter board for further extension.



ROBO-8710VLA System Block Diagram

Chapter 2

2. Hardware Configuration

This chapter indicates jumpers', headers' and connectors' location. Users may find useful information related to hardware settings in this chapter. The default settings are indicated with a star sign (★).

2-1 Jumper Setting

The jumper settings are used to select options for different features. The adjustment aims to let users customize ROBO-8710's features. In the following sections, **short** means covering a jumper cap over jumper pins; **open** or **N/C** (Not Connected) means removing a jumper cap from jumper pins.

Users can refer to Figure. 2-1 for the Jumper locations.




Figure.2-1 ROBO-8710VLA Jumper Location

CMOS Clear (JP1)

JP1	Function
1-2 Short	Clear CMOS Disable ★
2-3 Short	Clear CMOS Enable

COM2(J8) Interface Selection (JP2)

JP2	Function
5-6,9-11,10-12,15-17,16-18 Short	RS-232 ★
3-4,7-9,8-10,13-15,14-16,21-22 Short	RS-422
1-2,7-9,8-10,19-20 Short	RS-485

AT/ATX Power Selection (JP4)

JP4	Function
1-3, 2-4 Short	AT Power
3-5,4-6 Short	ATX Power ★

On-board VGA Enable/Disable (JP6 & JP7)

JP6	JP7	Function
N/C	N/C	Enable ★
1-2 Short	1-2 Short	Disable

LVDS Configuration (JP9)

LVDS Backlight-On Signal Selection (Pin 1~Pin 6)

JP9 1~6	Function
1-2, 5-6 Short	5V, Active Low
1-2, 4-6 Short	5V, Active High ★
1-3, 5-6 Short	12V, Active Low
1-3, 4-6 Short	12V, Active High

LVDS Panel Power (VDD) Selection (Pin 7~Pin 10)

JP9 7~10	Function
7-8 Short	5V ★
9-10 Short	3.3V

LVDS Resolution Selection (Pin 11~Pin 16)

JP9 11~16	Function
N/C	ID0 (Disable Panel) ★
11-12 Short	ID1 (800*600, 18 Bits)
13-14 Short	ID2 (1024*768, 18 Bits)
11-12, 13-14 Short	ID3 (1024*768, 24 Bits)

Note:

To avoid any harmful effect to LCD Panel, the power up sequence and scheme on the backlight and Panel VDD must be controlled by following the LVDS jumper setting instructions.

If higher resolution is needed, please contact Portwell for this.

2-2 Connector Allocation

I/O peripheral devices and flash disk are connected to the interface connectors and DOC socket on this single board computer (Figure 2-2)




Figure.2-2 ROBO-8710VLA Connector Location

Connector's Function List

Connector	Function	Remark
J1	Case-open Detection Connector	Connect to Chassis
J2	Secondary IDE Connector (IDE2)	
J3	Parallel Port Connector	
J4	External Thermal Sensor Connector	
J5	12V CPU Power Connector	
J6	Primary IDE Connector (IDE1)	
J7	FDC Interface Connector	
J8	COM2 Serial Port (RS-232/422/485)	
J9	COM1 Serial Port (RS-232)	
J10	General Purpose I/O Connector	
J11	ATX Power Control Connector	Connect to Backplane
J12	External USB Connector	
J13	Standalone Power Connector	
J14	LVDS Panel Control Connector	
J15	Wake On Ring Connector	
J16	ATX Power Button Interface	Connect to Chassis
J17	Reset Button Connector	Connect to Chassis
J18	External Speaker Connector	Connect to Chassis
J19	Power LED and Keyboard Lock Connector	Connect to Chassis
J20	Hard Disk Drive LED Connector	Connect to Chassis
J21	IrDA Connector	
J22	External Wake On LAN Connector	
J23	TMDS Panel Connector	
J24	Ethernet RJ-45 Connector	
J25	Power FAN Connector	
J26	Single-port USB Connector	

Connector	Function	Remark
J27	68-pin PCI Connector	
J28	PS/2 keyboard/Mouse Connector	6-pin Mini-DIN
J29	Audio MIC/Line-in/Line-out Connector	
J30	TV-out Connector	
J31	Audio CD-in Connector	
J32	On-board VGA CRT Connector	
J33	External keyboard Connector	Connect to Backplane
J34	CPU Fan Connector	
J35	System Fan Connector	
J36	SM-BUS Connector	
J40	LVDS Panel Connector	

Pin Assignments of Connectors

⌘ J1: Case-open Detection Connector

PIN No	Signal Description
1	Case-open Signal (Active low)
2	Ground

⌘ J3: Parallel Port Connector

PIN No.	Signal Description	PIN No.	Signal Description
1	Strobe#	14	Auto Form Feed#
2	Data 0	15	Error#
3	Data 1	16	Initialization#
4	Data 2	17	Printer Select IN#
5	Data 3	18	Ground
6	Data 4	19	Ground
7	Data 5	20	Ground
8	Data 6	21	Ground
9	Data 7	22	Ground
10	Acknowledge#	23	Ground
11	Busy	24	Ground
12	Paper Empty	25	Ground
13	Printer Select	26	N/C

⌘ J4: External Thermal Sensor Connector

PIN No	Signal Description
1	Thermistor Pin 1
2	Thermistor Pin 2

Note:

An external thermistor can be connected to these 2 pins for temperature monitoring remotely, such as chassis ambient temperature, etc. Normally, the resistance selected for thermistor should be 10KOhm at 25 degrees centigrade.

☐ **J5: 12V CPU supplementary Connector**

PIN No	Signal Description
1	Ground
2	Ground
3	+12V
4	+12V

☐ **J6/J2: Primary/Secondary IDE Connector (IDE1/IDE2)**

PIN No.	Signal Description	PIN No.	Signal Description
1	RESET#	2	Ground
3	Data 7	4	Data 8
5	Data 6	6	Data 9
7	Data 5	8	Data 10
9	Data 4	10	Data 11
11	Data 3	12	Data 12
13	Data 2	14	Data 13
15	Data 1	16	Data 14
17	Data 0	18	Data 15
19	Ground	20	N/C
21	DMA REQ	22	Ground
23	IOW#	24	Ground
25	IOR#	26	Ground
27	IOCHRDY	28	Pull-down
29	DMA ACK#	30	Ground
31	INT REQ	32	N/C
33	SA1	34	CBLID#
35	SA0	36	SA2
37	HDC CS0#	38	HDC CS1#
39	HDD Active#	40	Ground

☐ **J7: FDC Interface Connector**

PIN No.	Signal Description	PIN No.	Signal Description
1	Ground	2	Density Select 0
3	Ground	4	N/C
5	Ground	6	Density Select 1
7	Ground	8	Index#
9	Ground	10	Motor ENA#
11	Ground	12	Drive Select B#
13	Ground	14	Drive Select A#
15	Ground	16	Motor ENB#
17	Ground	18	Direction#
19	Ground	20	Step#
21	Ground	22	Write Data#
23	Ground	24	Write Gate#
25	Ground	26	Track 0#
27	Ground	28	Write Protect#
29	Ground	30	Read Data#
31	Ground	32	Head Select#
33	Ground	34	Disk Change#

♣ J9/J8 : COM1/COM2 Serial Port 1/2 Connector

PIN No.	Signal Description		
	RS-232	RS-422	RS-485
1	DCD (Data Carrier Detect)	TX-	DATA-
2	RXD (Receive Data)	TX+	DATA+
3	TXD (Transmit Data)	RX+	N/C
4	DTR (Data Terminal Ready)	RX-	N/C
5	GND (Ground)	GND	GND
6	DSR (Data Set Ready)	N/C	N/C
7	RTS (Request to Send)	N/C	N/C
8	CTS (Clear to Send)	N/C	N/C
9	RI (Ring Indicator)	N/C	N/C
10	N/C	N/C	N/C

Note:
 J9 is fixed as RS-232
 J8 is configurable as RS-232/422/485 with jumper JP2.

♣ J10: General Purpose I/O Connector

PIN No.	Signal Description
1	General Purpose I/O Port 1 (GPIO1)
2	General Purpose I/O Port 2 (GPIO2)
3	General Purpose I/O Port 3 (GPIO3)
4	General Purpose I/O Port 4 (GPIO4)
5	Ground
6	Buffered Digital Output Port 1 (DO1)
7	Buffered Digital Output Port 2 (DO2)
8	Buffered Digital Output Port 3 (DO3)
9	Buffered Digital Output Port 4 (DO4)
10	+5V

Note:
 All General Purpose I/O ports can only adapt standard TTL $\pm 5\%$ signal level (0V/5V). Pin 1~4 can be either input or output, while pin 6-10 can only be digital output.
 The 4 extra DO ports are provided for the applications that need higher driving capability. Through invert amplitude respected to GPIO port, each open-drain DO port can stand maximum fan out for up to 100mA, rather than 12mA direct driven by GPIO port.

♣ J11: ATX Power Control Connector

PIN No.	Signal Description
1	ATX Power Good Signal (PW-OK)
2	ATX 5V Stand-by (5VSB)
3	ATX Power On Control (PS-ON)
4	Ground

♣ J12: External USB Connector

PIN No.	Signal Description	PIN No.	Signal Description
1	5V Dual	2	Frame Ground
3	USB2-	4	Ground
5	USB2+	6	USB3+
7	Ground	8	USB3-
9	Frame Ground	10	5V Dual

Note:
 5V for pin1 and pin10 is always available. When the power scheme is in standby mode. The standby 5V supplies voltage source to these 2 pins. 5V VCC will take over after the system wakes up.

☺ **J13: Standalone Power Connector**

PIN No.	Signal Description
1	+12V
2	Ground
3	Ground
4	+5V

Note:
For system to run correctly in standalone operation. J3 and J5 both have to be connected.

☺ **J14: LVDS Panel Control Connector**

PIN No.	Signal Description
1	+12V
2	Ground
3	Panel VDD
4	Backlight-on Signal Output

☺ **J15: Wake On Ring Connector**

PIN No.	Signal Description
1	Ring Signal Input (Active low)
2	Ground

☺ **J16: ATX Power button Interface**

PIN No.	Signal Description
1	Pull-high 100 Ohm to +5V
2	Power Button Signal Input (Active high)

☺ **J17: Reset Button Connector**

PIN No	Signal Description
1	Reset Signal Input (Active low)
2	Ground

☺ **J18: External Speaker Connector**

PIN No.	Signal Description
1	Speaker Signal Output (Open-drain w/ internal series 33 Ohm)
2	N/C
3	Ground
4	+5V

Note:
The pull-high voltage of external speaker is limited at 5V maximum.

☺ **J19: Power LED and Keyboard Lock Connector**

PIN No.	Signal Description
1	+5V (330 Ohm pull-up for power LED+)
2	N/C
3	Ground (For Power LED-)
4	Keyboard Lock Signal Input (Active low)
5	Ground

☺ **J20: Hard Disk Drive LED Connector**

PIN No.	Signal Description
1	+5V (270 ohm pull-up for HDD LED+)

2	HDD Active # (HDD LED-)
---	-------------------------

☉ **J21: IrDA Connector**

PIN No.	Signal Description
1	+5V
2	N/C
3	IRRX
4	Ground
5	IRTX
6	N/C

☉ **J22: External Wake On LAN Connector**

PIN No.	Signal Description
1	5VSB
2	Ground
3	External WOL Signal Input (Active low)

☉ **J23: TMDS Panel Connector**

PIN No.	Signal Description	PIN No.	Signal Description
1	TMDS DATA0- (TX0N)	2	TMDS DATA0+ (TX0P)
3	Ground	4	Ground
5	TMDS DATA1- (TX1N)	6	TMDS DATA1+ (TX1P)
7	Ground	8	Ground
9	TMDS DATA2- (TX2N)	10	TMDS DATA2+ (TX2P)
11	Ground	12	Ground
13	TMDS CLOCK- (TXCN)	14	TMDS CLOCK+ (TXCP)
15	+5V	16	+5V
17	DVI DDC Clock (5V I/F)	18	DVI DDC Data (5V I/F)
19	Hot Plug Detect (HPD)	20	N/C

☉ **J24 : Ethernet RJ-45 Connector**

PIN No.	Signal Description
1	TD+
2	TD-
3	RD+
4	Termination to Ground
5	Termination to Ground
6	RD-
7	Termination to Ground
8	Termination to Ground

☉ **J25/J34/J35 : Power/CPU/System Fan Connector**

PIN No.	Signal Description
1	Ground
2	+12V PWM Output
3	Fan Speed Detecting signal

Note: Pin 2 supplies only +12 V. There is not any over current protection. Using any non-12V fan will be dangerous.

☉ **J26: Single-port USB Connector**

PIN No.	Signal Description
1	5V Dual

2	USB0-
3	USB0+
4	Ground

J27: 68-pin PCI Connector

PIN No.	Signal Description	PIN No.	Signal Description
1	+5V	2	AD0
3	AD1	4	AD2
5	AD3	6	AD4
7	AD5	8	AD6
9	AD7	10	Ground
11	+5V	12	AD8
13	AD9	14	AD10
15	AD11	16	AD12
17	AD13	18	AD14
19	AD15	20	Ground
21	+5V	22	AD16
23	AD17	24	AD18
25	AD19	26	AD20
27	AD21	28	AD22
29	AD23	30	Ground
31	+5V	32	AD24
33	AD25	34	AD26
35	AD27	36	AD28
37	AD29	38	AD30
39	AD31	40	Ground
41	+5V	42	C/BE#0
43	C/BE#1	44	C/BE#2
45	C/BE#3	46	PAR
47	FRAME#	48	TRDY#
49	IRDY#	50	Ground
51	+5V	52	STOP#
53	DEVSEL#	54	PERR#
55	SERR#	56	REQ#4
57	GNT#4	58	REQ#5
59	GNT#5	60	Ground
61	PCI Clock1	62	PCI Clock2
63	PCIRST#	64	LOCK#
65	IRQ#A	66	IRQ#B
67	IRQ#C	68	IRQ#D

⌘ **J28: PS/2 Keyboard/Mouse Connector**

PIN No.	Signal Description
1	Mouse Data
2	Keyboard Data
3	Ground
4	5V Dual
5	Mouse Clock
6	Keyboard Clock

J29: Audio MIC/Line-in/Line-out Connector

PIN No.	Signal Description	PIN No.	Signal Description
1	MIC with Reference Voltage	2	Analog Ground
3	Line-in Left Channel	4	Analog Ground
5	Line-in Right Channel	6	Analog Ground
7	Line-out Left Channel	8	Analog Ground
9	Line-out Right Channel	10	N/C

Note:
The Reference Voltage offers 2.25V~2.75V with 5mA drive.

⌘ J30: TV-out Connector

PIN No.	Signal Description	PIN No.	Signal Description
1	Ground	2	COMP/B
3	Y/G	4	C/R
5	SYNC	6	N/C

Vedio Interface Selection

	SCART RGB	S-video	Composite
C/R	Red	SVID C (Colour)	
Y/G	Green	SVID Y (Luminance)	
COMP/B	Blue		Composite Video
SYNC	Sync Signal		

Note:
Different video interfaces will be auto selected. The selection will be made base on the different impedance combination from each signal line.

⌘ J31: Audio CD-in Connector

PIN No.	Signal Description
1	CD-in Left Channel
2	CD Ground
3	CD Ground
4	CD-in Right Channel

⌘ J32: On-board VGA CRT Connector

PIN No.	Signal Description
1	Red
2	Green
3	Blue
4	Monitor ID0 (MONID0) (5V I/F)
5	Ground
6	Ground
7	Ground
8	Ground
9	+5V
10	Ground
11	Monitor ID1 (MONID1) (5V I/F)
12	VGA DDC Data (5V I/F)
13	Horizontal Sync. (HSYNC) (5V I/F)
14	Vertical Sync. (VSYNC) (5V I/F)
15	VGA DDC Clock (5V I/F)

⌘ J33: External Keyboard Connector

PIN No.	Signal Description
1	Keyboard Clock
2	Keyboard Data
3	N/C
4	Ground
5	5V Dual

⌘ **J36: SM-bus Connector**

PIN No	Signal Description
1	SM-bus Clock
2	N/C
3	Ground
4	SM-bus Data
5	+5V

J40: LVDS Panel Connector

PIN No.	Signal Description	PIN No.	Signal Description
1	Lower DATA0- (TXL0N)	2	Lower DATA0+(TXL0P)
3	Lower DATA1- (TXL1N)	4	Lower DATA1+(TXL1P)
5	Lower DATA2- (TXL2N)	6	Lower DATA2+(TXL2P)
7	Lower DATA3- (TXL3N)	8	Lower DATA3+(TXL3P)
9	Lower CLOCK- (TXLCN)	10	Lower CLOCK+(TXLCP)
11	Upper DATA0- (TXU0N)	12	Upper DATA0+(TXU0P)
13	Upper DATA1- (TXU1N)	14	Upper DATA1+(TXU1P)
15	Upper DATA2- (TXU2N)	16	Upper DATA2+(TXU2P)
17	Upper DATA3- (TXU3N)	18	Upper DATA3+(TXU3P)
19	Upper CLOCK- (TXUCN)	20	Upper CLOCK+(TXUCP)

Note:

It only takes the lower channel to support panels with high resolution. The signals of the upper channel will only be used in dual-channel LVDS mode.

This panel connector (J40) should be accompanied with LVDS Panel Control Connector (J14) and its jumper setting (JP9)

Lower channel equals odd channel; upper channel equals even channel for different panel description.

CHAPTER 3

System Installation

This chapter provides you with instructions to set up your system. The additional information is enclosed to help you install M-systems Flash disk, set up onboard PCI device and handle WDT operation in software programming.

3-1 Pentium 4 Processor

Installing 478 Pin CPU

- 1) Lift the handling lever of CPU socket outwards and upwards to the other end.
- 2) Align the processor pins with pinholes on the socket. Make sure that the notched corner or dot mark (pin 1) of the CPU corresponds to the socket's bevel end. Then press the CPU gently until it fits into place. If this operation is not easy or smooth, don't do it forcibly. You need to check and rebuild the CPU pin uniformly.
- 3) Push down the lever to lock processor chip into the socket once CPU fits.
- 4) Follow the installation guide of cooling fan or heat sink to mount it on CPU surface and lock it on the socket 478.

Removing CPU

- 1) Unlock the cooling fan first.
- 2) Lift the lever of CPU socket outwards and upwards to the other end.
- 3) Carefully lift up the existing CPU to remove it from the socket.
- 4) Follow the steps of installing a CPU to change to another one or place handling bar to close the opened socket.

Configuring System Bus

ROBO-8710VLA will automatically detect the CPU used. CPU speed of Intel P4 can be detected automatically.

3-2 Main Memory

ROBO-8710VLA provides two DDR-SDRAM DIMM slots to support 2.5V DDR-SDRAM as on-board main memory. The maximum memory size can be up to 2GB. Auto detecting memory clock according to BIOS CMOS settings.

For system compatibility and stability, don't use memory module without brand. You can also use only one double-sided DIMM in either one DIMM slot or two single-sided DIMM in both slots.

Watch out the contact and lock integrity of memory module with socket, it will impact on the system reliability. Follow normal procedures to install your DRAM module into memory socket. Before locking, make sure that all modules have been fully inserted into the card slots.

NOTE :

- (1) To maintain system stability, don't change any of DRAM parameters in BIOS setup to upgrade your system performance without acquiring technical information.**

3-3 M-systems Flash Disk

ROBO-8710VLA reserves one 32-pin DIP sockets for installing M-systems Flash disk from 2MB to 512MB. This operation structure is running with pure ISA-bus without PnP (Plug and Play) function. Before installing, make sure that I/O address jumper setting is set on right position to prevent unworkable system due to I/O resource conflict. Do remember to follow DOC (DiskOnChip) installation procedure. Otherwise, it is possible to burn out the Flash chip due to incorrect installation.

Installing DOC

Align the DOC with pinholes on the socket. Make sure that the notched corner or dot mark (pin 1) of DOC corresponds to notched corner of the socket. Then press the DOC gently until it fits into place. If installation procedure is correct, the Flash disk can be viewed as a normal hard disk to access read/write data.

WARNING

Please ensure that your DOC is properly inserted. Placing the DOC in reverse will cause severe damage. Remember, a new DOC chip is always a formatted disk. You may simply plug the chip on the DOC socket and read/write through it. If you would like to boot from this Flash disk, it is necessary to refer to the application note from M-systems. You can easily get relative information from M-systems shipping package (such as product manual) or Web-site <http://www.m-sys.com>.

3-4 Installing the Single Board Computer

To install your ROBO-8710VLA into standard chassis or proprietary environment, you need to perform the following:

- Step 1 : Check all jumpers setting on proper position
- Step 2 : Install and configure CPU and memory module on right position
- Step 3 : Place ROBO-8710VLA into the dedicated position in your system
- Step 4 : Attach cables to existing peripheral devices and secure it

WARNING

Please ensure that your SBC is properly inserted and fixed by mechanism. Otherwise, the system might be unstable or do not work due to bad contact of golden finger and ISA-bus slot.

NOTE : Please refer to section 3-4-1 to 3-4-3 to install INF/VGA/LAN drivers.

3-4-1 Chipset Component Driver

The chipset on ROBO-8710VLA is a new chipset that a few old operating systems might not be able to recognize. **To overcome this compatibility issue, for Windows Operating Systems such as Windows-95/98/98SE/2000, please install its INF before any of other Drivers are installed.** You can find very easily this chipset component driver in ROBO-8710VLA CD-title.

3-4-2 ATI Mobility Radeon Graphic Integrated Chipset

Using ATI Mobility Radeon High performance graphic integrated chipset is aimed to gain an outstanding graphic performance at a cost effective price. It is accompanied by a 16MB DDR-SDRAM. This combination makes ROBO-8710 VLA an excellent piece of multimedia hardware.

With no additional video adaptor, this onboard video will usually be the system display output. By adjusting the JP6 jumper to disable on-board VGA, an add-on PCI or ISA VGA card can take over the system display.

Drivers Support

Please find ATI Mobility Radeon driver in the ROBO-8710VLA CD-title. Drivers support Windows-98/98SE/ME, Windows-NT 3.51/4.0, Windows-2000, OS2, and Linux.

- (1) Windows-98/98SE: Please execute **exe** file to start graphics driver installation, or bring up the Display Control Panel and update graphics driver.
- (2) Windows-NT 4.0: Please install Windows-NT 4.0 Service Pack 4 or above first, then execute **exe** file, or simply bring up the Display Control Panel and update graphics driver.
- (3) Windows-2000: Please bring up the Device Manager and update graphics drivers.
- (4) Redhat Linux V6.2: Please refer to the related documentation in for graphic drivers installation.

3-4-3 On-board Fast Ethernet Controller

Drivers Support

Please find Intel 82801BA ICH2 LAN driver in /Ethernet directory of ROBO-8710VLA CD-title. The drivers support Windows-NT 4.0, Windows-98/98SE/ME, Windows-2000, Windows-XP, and Linux.

On-board LED Indicator (for LAN status)

ROBO-8710VLA provides three LED indicators to report 82801BA MAC Fast Ethernet interfaces status. Please refer to the table below as a quick reference guide.

82801BA	Name of LED	Operation of Ethernet Port	
		ON	Off
LED1	LAN Link Integrity LED	Good link in 10 or 100 Mbps	Bad link
LED2	LAN active LED	Active	No active
LED3	LAN speed LED	100 Mbps	10 Mbps

3-4-4 On-board AC-97 Audio Device

The on-board AC-97 audio device provides a more than standard sound display. It is capable for many general purposes.

3-4-5 On-board 68-pin PCI connector

ROBO-8710VLA provides one on-board 68-pin PCI connector that allows you to apply additional PCI devices, such as SCSI or Ethernet. If you have a compatible PCI device, simply plug it onto the connector and secure it with two retention bars.

3-5 Clear CMOS Operation

The following table indicates how to enable/disable CMOS Clear Function hardware circuit by putting jumpers at proper position.

JP1	FUNCTION
1-2 Short	Clear CMOS Disable ★
2-3 Short	Clear CMOS Enable

To correctly operate CMOS Clear function, users must turn off the system, move JP1 jumper to short pin 2 and 3. To clear CMOS, please turn the power back on and turn it off again for AT system, or press the toggle switch a few times for ATX system. Move the JP1 back to 1-2 position (Normal Operation) and start the system. System will then produce a "CMOS Check Sum Error" message and hold up. Users may then follow the displayed message to load BIOS default setting.

3-6 WDT Function

The working algorithm of the WDT function can be simply described as a counting process. The Time-Out Interval can be set through software programming. The availability of the time-out interval settings by software or hardware varies from boards to boards. ROBO-8710VLA allows users control WDT through dynamic software programming. The WDT starts counting when it is activated. It sends out a signal to system reset or to non-maskable interrupt (NMI), when time-out interval ends. To prevent the time-out interval from running out, a re-trigger signal will need to be sent before the counting reaches its end. This action will restart the counting process. A well-written WDT program should keep the counting process running under normal condition. WDT should never generate a system reset or NMI signal unless the system runs into troubles.

The related Control Registers of WDT are all included in the following sample program that is written in C language. User can fill a non-zero value into the Time-out Value Register to enable/refresh WDT. System will be reset after the Time-out Value to be counted down to zero. Or user can directly fill a zero value into Time-out Value Register to disable WDT immediately. To ensure a successful accessing to the content of desired

Control Register, the sequence of following program codes should be step-by-step run again when each register is accessed. Additionally, there are maximum 2 seconds of counting tolerance that should be considered into user' application program. For more information about WDT, please refer to Winbond W83627HF data sheet that is attached in CD accessory.

There are two PNP I/O port addresses that can be used to configure WDT,
0x2E:EFIR (Extended Function Index Register, for identifying CR index number)
0x2F:EFDR (Extended Function Data Register, for accessing desired CR)

Below are some example codes, which demonstrate the use of WDT.

```
// Enter Extended Function Mode
outp(0x002E, 0x87);
outp(0x002E, 0x87);
// Assign Pin 89 to be a WDIO
outp(0x002E, 0x2B);
outp(0x002F, inp(0x002F) & 0xEF);
// Select Logic Device 8
outp(0x002E, 0x07);
outp(0x002F, 0x08);
// Active Logic Device 8
outp(0x002E, 0x30);
outp(0x002F, 0x01);
// Select Count Mode
outp(0x002E, 0xF5);
outp(0x002F, (inp(0x002F) & 0xF7) | (Count-mode Register & 0x08));
// Specify Time-out Value
outp(0x002E, 0xF6);
outp(0x002F, Time-out Value Register);
// Disable WDT reset by keyboard/mouse interrupts
outp(0x002E, 0xF7);
outp(0x002F, 0x00);
// Exit Extended Function Mode
outp(0x002E, 0xAA);
```

Definitions of Variables:

- Value of **Count-mode Register**:
- 1) 0x00 -- Count down in seconds (Bit3=0)
 - 2) 0x08 -- Count down in minutes (Bit3=1)
- Value of **Time-out Value Register**:
- 1) 0x00 -- Time-out Disable
 - 2) 0x01~0xFF -- Value for counting down

3-7 SMBUS

The System Management Bus is a two-wire interface through which simple power-related chips can communicate with rest of the system. It uses I2C as its backbone.

A system using SMB passes messages to and from devices instead of tripping individual control lines.

With the SMBus, a device can provide manufacturer information, tell the system what its model/part number is, save its state for a suspend event, report different types of errors, accept control parameters, and return its status.

The SMBus may share the same host device and physical bus as ACCESS bus components provided that an appropriate electrical bridge is provided between the internal SMB devices and external ACCESS bus devices.

3-8 Display Output

LCD

There are two LCD panel interfaces provided in this system, TMDS and LVDS are two interfaces available on ROBO-8710VLA..

TV

Composite Video, S-video and Scart R/G/B interfaces are 3 kinds of TV outputs provided by this system. Please refer to connector J30 for more details. Each time the system is on, the system auto-detects one interface for outputting display information. A connection to a different interface will result a particular impedance combination of signal lines. The selection will be made base on the

different impedances of each signal line.

3-9 GPIO

The ROBO-8710VLA provides 4 input/output ports that can be individually configured to perform a simple basic I/O function or a pre-defined alternated function. Users can configure each individual port to become an input or output port by programming register bit of I/O Selection. To invert port value, the setting of Inversion Register has to be made. Port values can be set to read or write through Data Register. All of these 4 ports are designed to be functional even in power loss condition (VCC or VSB is off). That means, these ports will always keep their previous settings until battery runs low.

Additionally, 4-extra Digital Output ports inversely amplified signals from GPIO ports. There are open-drain buffers, which can offer greater driving capacity up to 100mA.

There are two PNP I/O port addresses that can be used to configure GPIO ports, 0x2E:EFIR (Extended Function Index Register, for identifying CR index number) 0x2F:EFDR (Extended Function Data Register, for accessing desired CR)

Below are some example codes, which demonstrate the use of GPIO.

```
// Enter Extended Function Mode
outp(0x002E, 0x87);
outp(0x002E, 0x87);
// Assign Pin121-128 to be GPIO port 1
outp(0x002E, 0x2A);
outp(0x002F, inp(0x002F) | 0x84);
// Select Logic Device 7
outp(0x002E, 0x07);
outp(0x002F, 0x07);
// Active Logic Device 7
outp(0x002E, 0x30);
outp(0x002F, 0x01);
// Select Inversion Mode
outp(0x002E, 0xF2);
outp(0x002F, (inp(0x002F) & 0x0F) | Inversion Register & 0xF0));
```

```
// Select I/O Mode
outp(0x002E, 0xF0);
outp(0x002F, (inp(0x002F) & 0x0F) | (I/O Selection Register & 0xF0));
// Access GPIO ports
outp(0x002E, 0xF1);
outp(0x002F, (inp(0x002F) & 0x0F) | (Output Data & 0xF0));
or
Input Data = inp(0x002F);
// Exit Extended Function Mode
outp(0x002E, 0xAA);
```

Definitions of Variables:

Each bit in the high nibble of each Register represents the setting of a GPIO port.

Bit4 vs. GPIO port 1

Bit5 vs. GPIO port 2

Bit6 vs. GPIO port 3

Bit7 vs. GPIO port 4

Value of **Inversion Register**:

Only high nibble is available for this function.

When set to a '1', the incoming/outgoing port value is inverted.

When set to a '0', the incoming/outgoing port value is the same as in Data Register.

Value of **I/O Selection Register**:

Only high nibble is available for this function.

When set to a '1', respective GPIO port is programmed as an input port.

When set to a '0', respective GPIO port is programmed as an output port.

Value of **Output Data** / **Input Data**:

Only high nibble is available for this function.

If a port is assigned to be an output port, then its respective bit can be read/written.

If a port is assigned to be an input port, then its respective bit can be read only.

Notice:

1) All the Buffered Digital Outputs are open-drain amplified form respected GPIO ports.

2) Some other functions may occupy the lower nibble of the registers. Altering

any content in lower nibble will be undesired.

CHAPTER 4

BIOS Setup Information

ROBO-8710VLA is equipped with the AWARD BIOS stored in Flash ROM. This BIOS has a built-in Setup program that allows users to modify the basic system configuration easily. This type of information is stored in CMOS RAM so that it is retained during power-off periods. When system is turned on, ROBO-8710VLA communicates with peripheral devices and check its hardware resources against the configuration information stored in the CMOS memory. If any error is detected, or the CMOS parameters need to be initially defined, the diagnostic program will prompt the user to enter the SETUP program. Some errors are significant enough to abort the start-up.

4.1 Entering Setup

Turn on or reboot the computer. When the message “Hit if you want to run SETUP” appears, press key immediately to enter BIOS setup program.

If the message disappears before you respond, but you still wish to enter Setup, please restart the system to try “COLD START” again by turning it OFF and then ON, or touch the "RESET" button. You may also restart from “WARM START” by pressing <Ctrl>, <Alt>, and <Delete> keys simultaneously. If you do not press the keys at the right time and the system will not boot, an error message will be displayed and you will again be asked to,

Press <F1> to Run SETUP or Resume

In HIFLEX BIOS setup, you can use the keyboard to choose among options or modify the system parameters to match the options with your system. The table below will show you all of keystroke functions in BIOS setup.

Keys to navigate within setup menu

Key	Functions
Up Arrow	Move to the previous item
Down Arrow	Move to the next item
Left Arrow	Move to the item on the left (menu bar)
Right Arrow	Move to the item on the right (menu bar)
Move Enter	Move to the item you desired
PgUp key	Increase the numeric value or make changes
PgDn key	Decrease the numeric value or make changes
+ key	Increase the numeric value or make changes
- key	Decrease the numeric value or make changes
Esc key	Main Menu -- Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
F1 key	General help on Setup navigation keys
F5 key	Load previous values from CMOS
F6 key	Load the fail-safe defaults from BIOS default table
F7 key	Load the optimized defaults
F10 key	Save all the CMOS changes and exit

4.2 Main Menu

Once you enter ROBO-8710VLA AWARD BIOS CMOS Setup Utility, you should start with the Main Menu. The Main Menu allows you to select from eleven setup functions and two exit choices. Use arrow keys to switch among items and press <Enter> key to accept or bring up the sub-menu.

Phoenix-AwardBIOS CMOS Setup Utility	
Standard CMOS Features	Frequency/Voltage Control
Advanced BIOS Features	Load Fail-Safe Defaults
Advanced Chipset Features	Load Optimized Defaults
Integrated Peripherals	Set Supervisor Password
Power Management Setup	Set User Password
PnP/PCI Configurations	Save & Exit Setup
PC Health Status	Exit Without Saving
Esc : Quit	↑ ↓ ← → : Select Item
F10 : Save & Exit Setup	
Time, Date, Hard Disk Type....	

NOTE : It is strongly recommended to reload Optimal Setting if CMOS is lost or BIOS is updated.

4.3 Standard CMOS Setup Menu

This setup page includes all the items in a standard compatible BIOS. Use the arrow keys to highlight the item and then use the <PgUp>/<PgDn> or <+>/<-> keys to select the value or number you want in each item and press <Enter> key to certify it.

Follow command keys in CMOS Setup table to change **Date**, **Time**, **Drive type**, and **Boot Sector Virus Protection Status**.

■ **Screen shot**

Standard CMOS Features		
Date: (mm:dd:yy)	Mon, Oct 2 1999	Item Help
Time: (hh:mm:ss)	16:51:13	
➤ IDE Primary Master	None	Menu Level ➤
➤ IDE Primary Slave	None	Change the day, month, year and century
➤ IDE Secondary Master	None	
➤ IDE Secondary Slave	None	
Drive A	1.44M, 3.5 in.	
Drive B	None	
Video	EGA/VGA	
Halt On	All, But Keyboard	
Based Memory	640K	
Extended Memory	260096K	
Total Memory	261120K	
↑↓→←Move Enter: Select +/-/PU/PD: Value F10:Save ESC: Exit F1:General Help F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults		

■ **Menu selections**

Item	Options	Description
Date	Mm:dd:yy	Set the system date. Note that the 'Day' automatically changes when you set the date
Time	Hh:mm:ss	Set the system time
IDE Primary Master	Options are in its sub menu (described in 4.4 Table)	Press <Enter> to enter the sub menu of detailed options
IDE Primary Slave	Options are in its sub menu (described in 4.4 Table)	Press <Enter> to enter the sub menu of detailed options
IDE Secondary Master	Options are in its sub menu (described in 4.4 Table)	Press <Enter> to enter the sub menu of detailed options
IDE Secondary Slave	Options are in its sub menu (described in 4.4 Table)	Press <Enter> to enter the sub menu of detailed options

Item	Options	Description
Drive A Drive B	None 360K, 5.25 in 1.2M, 5.25 in 720K, 3.5 in 1.44M, 3.5 in 2.88M, 3.5 in	Select the type of floppy disk drive installed in your system
Video	EGA/VGA CGA 40 CGA 80 MONO	Select the default video device
Halt On	All Errors No Errors All, but Keyboard All, but Diskette All, but Disk/Key	Select the situation in which you want the BIOS to stop the POST process and notify you
Base Memory	N/A	Displays the amount of conventional memory detected during boot up
Extended Memory	N/A	Displays the amount of extended memory detected during boot up
Total Memory	N/A	Displays the total memory available in the system

4.4 IDE Adaptors Setup Menu

The IDE adaptors control the IDE devices, such as hard disk drive or cdrom drive. It uses a separate sub menu to configure each hard disk drive.

■ Screen shot

Phoenix- AwardBIOS CMOS Setup Utility
IDE Primary Master

IDE HDD Auto-Detection	Press Enter	Item Help
IDE Primary Master	Auto	Menu Level >>
Access Mode	Auto	To auto-detect the HDD's size, head...
Capacity	20491 MB	on this channel
Cylinder	39703	
Head	16	
Precomp	0	
Landing Zone	39702	
Sector	63	
↑↓→← Move Enter: Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults		

■ **Menu selections**

Item	Options	Description
IDE HDD Auto-detection	Press Enter	Press Enter to auto-detect the HDD on this channel. If detection is successful, it fills the remaining fields on this menu.
IDE Primary Master	None Auto Manual	Selecting 'manual' lets you set the remaining fields on this screen. Selects the type of fixed disk. "User Type" will let you select the number of cylinders, heads, etc. Note: PRECOMP=65535 means NONE !
Access Mode	CHS LBA Large Auto	Choose the access mode for this hard disk
Capacity	Auto Display your disk drive size	Disk drive capacity (Approximated). Note that this size is usually slightly greater than the size of a formatted disk given by a disk checking program.
The following options are selectable only if the 'IDE Primary Master' item is set to 'Manual'		
Cylinder	Min = 0 Max = 65535	Set the number of cylinders for this hard disk.
Head	Min = 0 Max = 255	Set the number of read/write heads
Precomp	Min = 0 Max = 65535	**** Warning: Setting a value of 65535 means no hard disk
Landing zone	Min = 0 Max = 65535	****
Sector	Min = 0 Max = 255	Number of sectors per track

4.5 Advanced BIOS Features

This section allows you to configure your system for basic operation. You have the opportunity to select the system's default speed, boot-up sequence, keyboard operation, shadowing and security.

■ Screen shot

Phoenix – AwardBIOS CMOS Setup Utility
Advanced BIOS Features

Virus Warning	Disabled	Item Help
CPU L1 & L2 Cache	Enabled	
Quick Power On Self Test	Enabled	Menu Level >
First Boot Device	Floppy	
Second Boot Device	HDD-0	
Third Boot Device	LS120	
Boot Other Device	Enabled	
Swap Floppy Drive	Disabled	
Boot Up Floppy Seek	Enabled	
Boot Up NumLock Status	On	
Get A20 Option	Fast	
Typematic Rate Setting	Disabled	
Typematic Rate (Chars/sec)	6	
Typematic delay (Msec)	250	
Security Option	Setup	
OS Select For DRAM > 64MB	Non-OS2	
Report no FDD for Win 95	No	
Small logo(EPA)show	Disabled	
↑↓←→Move Enter: Select +/-/PU/PD: Value F10:Save ESC: Exit F1:General Help F5:Previous Values F6:Fail-safe defaults F7:Optimized Defaults		

Virus Warning

Enabled	Activates automatically when the system boots up causing a warning message to appear when anything attempts to access the boot sector or hard disk partition table.
Disabled	No warning message will appear when anything attempts to access the boot sector or hard disk partition table.

CPU L1 Cache/L2 Cache

These two categories speed up memory access. However, it depends on CPU/chipset design.

Enabled	Enable cache
Disabled	Disable cache

Quick Power On Self Test

This category speeds up Power On Self Test (POST) after you power up the computer. If it is set to Enable, BIOS will shorten or skip some check items during POST.

Enabled	Enable quick POST
Disabled	Normal POST

First/Second/Third/Other Boot Device

The BIOS attempts to load the operating system from the devices in the sequence selected in these items.

The Choice: Floppy, LS120, ZIP100, HDD, SCSI, CDROM, HDD-1, HDD-2, HDD3, LAN and Disabled.

Swap Floppy Drive

If the system has two floppy drives, choose enable to assign physical driver B to logical drive A and Vice-Versa.

The choice: Enabled/Disabled.

Boot Up Floppy Seek

Enabled tests floppy drives to determine whether they have 40 or 80 tracks

The choice: Enabled/Disabled.

Boot Up NumLock Status

Select power on state for NumLock.

The choice: Off/On.

Get A20 Option

Fast-lets chipsets control Gate A20 and normal – a pin in the keyboard controller controls Gate A20.

The choice: Normal/Fast

Typematic Rate Setting

Keystrokes repeat at a rate determined by the keyboard controller – When enabled, the typematic rate and typematic delay can be select.

The choice: Enabled/Disabled.

Typematic Rate (Chars/sec)

This option will only available when Typematic Rate Setting is set to enable. The unit is character per second.

Typematic delay (Msec)

This option will only available when Typematic Rate Setting is set to enable. The delay is in Msec.

Security Option

Select whether the password is required every time the system boots or only when you enter setup.

System	The system will not boot and access to Setup will be denied if the correct password is not entered at the prompt.
Setup	The system will boot, but access to Setup will be denied if the correct password is not entered at the prompt.

Note : To disable security, select PASSWORD SETTING at Main Menu and then you will be asked to enter password. Do not type anything and just press <Enter>, it will disable security. Once the security is disabled, the system will boot and you can enter Setup freely.

OS Select For DRAM > 64MB

Select the operating system that is running with greater than 64MB of RAM on the system.

The choice: Non-OS2, OS2.

4.6 Advanced Chipset Features

This section allows you to configure the system based on the specific features of the Intel 82845 chipset. This chipset manages bus speeds and access to system memory resources, such as DRAM (SDRAM) and the external cache. It also coordinates communications between the conventional ISA bus and the PCI bus. It must be stated that these items should never need to be altered. The default settings have been chosen because they provide the best operating conditions for your system. The only time you might consider making any changes would be if you discovered that data was being lost while using your system.

■ Screen shot

CMOS Setup Utility – Copyright © 1984 – 2000 Award Software
Advanced Chipset Features

		Item Help
DRAM Timing Selectable	By SPD	
CAS Latency Time	1.5	
Active to Precharge Delay	7	
DRAM RAS#-to-CAS# Delay	3	
DRAM RAS# Precharge	3	
DRAM Data Integrity Mode	Non-ECC	
Memory Frequency For	Auto	
Dram Read Thermal Mgmt	Disabled	
System BIOS Cacheable	Enabled	
Video BIOS Cacheable	Disabled	
Memory Hole AT 15-16M	Disabled	
Delayed Transaction	Enabled	
Delay Prior to Thermal	16 Min	
AGP Aperture Size(MB)	64	
↑↓←→Move Enter: Select +/-/PU/PD: Value F10:Save ESC: Exit F1:General Help F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults		Menu Level >

This chipset settings deal with CPU access to dynamic random access memory (DRAM). The default timings have been carefully chosen and should only be altered if data is being lost. Such a scenario might well occur if your system had mixed speed DRAM chips installed so that greater delays may be required to preserve the integrity of the data held in the slower memory chips.

DRAM Time Selectable

This option provides DIMM lug-and-play support by serial presence detect (SPD) mechanism via the system management bus (SMBUS) interface.

The choice: Manual/ By SPD

CAS Latency Time

This option controls the number of SCLKs between the time a read command is sampled by the SDRAMs and the time the GMCH samples correspondent data from the SDRAMs.

The Choice: 1.5, 2, 2.5, 3 SCLKs.

Active to Precharge Delay

This is to DDR standard accordingly.

The choice: 7, 6, 5

DRAM RAS-to-CAS Delay

This option controls the number of SCLKs (SDRAM Clock) from a row activate command to a read or write command. If your system installs good quality of SDRAM, you can set this option to “3 SCLKs” to obtain better memory performance. Normally, the option will be set to Auto.

The Choice: 2 or 3

DRAM RAS Precharge

This option controls the number of SCLKs for RAS# precharge. If your system installs good quality of SDRAM, you can set this option to “3 SCLKs” to obtain better memory performance. It is set to auto normally.

The Choice: 2 or 3

DRAM Data Integrity Mode

There are two options available. The DRAM integrity mode will be implemented by the parity algorithm when this option is set to “Non-ECC”.

The choice: Non ECC/ ECC.

Memory Frequency For

Users are recommended to use Auto for memory frequency selection.

The choice: DDR200/DDR266/Auto

DRAM Read Thermal Mgmt

DRAM Read Thermal Management has options, enable and disable.

The choice: Enabled/Disabled.

System BIOS Cacheable

Selecting Enabled allows caching of the system BIOS ROM at F0000h-FFFFFh, resulting in better system performance. However, if any program writes to this memory area, a system error may result.

The choice: Enabled/Disabled.

Video BIOS Cacheable

Select "Enabled" to enable caching VGA BIOS into L2 cache to get higher display performance. "Disabled" will ignore this BIOS caching function.

The choice : Enabled/Disabled

Memory Hole At 15-16M

In order to improve performance, certain space in memory is reserved for ISA cards. This memory must be mapped into the memory space below 16MB.

The Choice: Enabled/Disabled.

Delayed Transaction

Select "Enabled" to enable delay transaction. This will enhance performance for data transmission between different PCI bus.

The Choice: Enabled/Disabled.

4.7 Integrated Peripherals

■ Screen shot

CMOS Setup Utility – Copyright © 1984 – 2001 Award Software

Integrated Peripherals

On-Chip Primary PCI IDE	Enabled	Item Help
IDE Primary Master PIO	Auto	Menu Level >
IDE Primary Slave PIO	Auto	
IDE Primary Master UDMA	Auto	
IDE Primary Slave UDMA	Auto	
On-Chip Secondary PCI IDE	Enabled	
IDE Secondary Master PIO	Auto	
IDE Secondary Slave PIO	Auto	
IDE Secondary Master UDMA	Auto	
IDE Secondary Slave UDMA	Auto	
USB Controller	Enabled	
USB Keyboard Support	Disabled	
USB Mouse Support	Disabled	
AC97 Audio	Auto	
AC97 Modem	Auto	
Init Display First	AGP	
IDE HDD Block Mode	Enabled	
POWER ON Function	BUTTON ONLY	
KB Power On Password	Enter	
Hot Key Power On	Ctrl-F1	
Onboard FDC Controller	Enabled	
Onboard Serial Port 1	3F8/IRQ4	
Onboard Serial Port 2	2F8/IRQ3	
UART Mode Select	Normal	
RxD , TxD Active	Hi-Low	
IR Transmission Delay	Enabled	
UR2 Duplex Mode	Half	
Use IR Pins	IR-Rx2Tx2	
Onboard Parallel Port	378/IRQ7	
Parallel Port Mode	SPP	
EPP Mode Select	EPP1.7	
ECP Mode Use DMA	3	
PWRON After PWR-Fail	off	
Midi Port Address	330	
Midi Port IRQ	10	
Watch Dog Timer Select	Disabled	
DOC Memory Address Range	D8000-D9FFF	
↑↓←→ Move Enter: Select +/-/PU/PD: Value F10:Save ESC: Exit F1:General Help F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults		

OnChip Primary/Secondary PCI IDE

The chipset contains a PCI IDE interface with support for two IDE channels. Select Enabled to activate the primary IDE interface. Select Disabled to deactivate this interface

The choice: Enabled/Disabled.

IDE Primary/Secondary Master/Slave PIO

The four IDE PIO (Programmed Input/Output) fields let you set a PIO mode (0-4) for each of the four IDE devices that the onboard IDE interface supports. Modes 0 through 4 provide successively increased performance. In Auto mode, the system automatically determines the best mode for each device.

The choice: Auto, Mode 0, Mode 1, Mode 2, Mode 3, Mode 4.

IDE Primary/Secondary Master/Slave UDMA

Ultra DMA/33/66/100 implementation is possible only if your IDE hard drive supports it and the operating environment includes a DMA driver (Windows 95 OSR2 or a third-party IDE bus master driver). If your hard drive and your system software both support Ultra DMA/33/66/100, select Auto to enable BIOS support.

The Choice: Auto, Disabled.

USB Controller

This item allows you to enable/disable USB (Universal Serial Bus) function.

The choice: Enabled/Disabled

USB Keyboard Support

This item allows you to enable USB keyboard function under POST, BIOS setup menu, DOS, or Windows-NT with no USB driver loaded.

The choice: Enabled/Disabled

USB Mouse Support

To enable or disable the USB mouse control.

The choice: Enabled/Disabled.

Init Display First

This item allows you to select the first display port to be initialized.

The choice: PCI Slot (off-board video adaptor), AGP

IDE HDD Block Mode

This item allows you to enable/disable IDE HDD Block Mode. The function is to collect the data that is nearby the one being read and leave them in the system buffer. Buffered data can be used with faster transmission rate so as to enhance system performance.

The choice: Enabled/Disabled

Power On Function

This item allows you to select different power on scheme using ATX power supply.

Password	Power on using customized password string
Hot Key	Power on using special customized key
Mouse Left	Power on using mouse left click
Mouse Right	Power on using mouse right click
Any Key	Power on using any keyboard key
Button Only	Power on by power Button
Keyboard 98	Power on by keyboard 98

Keyboard Power On Password

In the event of “Power On Function” being configured as “Password”, this item will be enabled for tuning. Press “Enter” key to enter a customized password, and confirm again when being asked. In the case that the confirmed password does not match the configured one, the message of “Password Disabled – Press any key to continue...” will be prompted.

Hot Key Power On

In the event of “Power On Function” being configured as “Hot Key”, this item will be enabled for tuning.

The choice: Ctrl-F1 to Ctrl-F12.

Onboard FDC Controller

This item allows you to enable/disable onboard Floppy disk controller.

The choice: Enabled/Disabled

Onboard Serial Port 1/Port 2

Select an address and corresponding interrupt for the first and second serial ports.

The choice: 3F8/IRQ4, 2E8/IRQ3, 3E8/IRQ4, 2F8/IRQ3, Disabled, Auto.

UART Mode Select

This item allows users to select Infrared transmission mode.

Normal	Disable Infrared function
IrDA	Select IrDA mode transmission
ASKIR	Select ASKIR mode transmission

As Infrared transmission function shares onboard serial port 2, COM2 needs to be enabled.

RxD, TxD Active

This item is to configure Infrared transmission rate. Four options are available :

Hi, Hi	High rate for receiving / High rate for transmitting
Hi, Lo	High rate for receiving / Low rate for transmitting
Lo, Hi	Low rate for receiving / High rate for transmitting
Lo, Lo	Low rate for receiving / Low rate for transmitting

IR Transmission Delay

This option will be available when IR is enabled.

The choice: Enabled/Disabled.

UR2 Duplex Mode

The available choices are full duplex mode and half duplex mode

The choice: Full/Half.

Use IR Pins

The available choices are IR-Rx2Tx2/ RxD2, TxD2.

The choice: IR-Rx2Tx2 / RxD2, TxD2.

Onboard Parallel Port

This item allows you to configure I/O address of the onboard parallel port.

The Choices : Disabled, 378/IRQ7, 278/IRQ5, 3BC/IRQ7

Parallel Port Mode

There are four different modes for the onboard parallel port :

SPP	Switch to SPP mode
EPP	Switch to EPP mode
ECP	Switch to ECP mode
ECP + EPP	Switch to ECP + EPP mode
Normal	Switch to Normal mode

EPP Mode Select

Select different version of EPP mode.

The choices : EPP1.7/EPP1.9

ECP Mode Use DMA

Select a proper DMA channel for ECP mode.

The choices : 3/1

PWRON After PWR-Fail

This item allows user to configure the power status of using ATX power supply after a serious power loss occurs.

On	System automatically restores power back
Off	System stays at power -off
Former-Sts	System restores back to previous status (On or Off)

Midi Port Address

There are 4 choices. There are disable, 330, 300 and 290.

The choice: Disabled/330/300/290.

Midi Port IRQ

To assign an IRQ number to Midi Port.

The choice: 5/10.

Watch Dog Timer Select

This BIOS testing option is able to reset the system according to the selected table.

The choice: Disabled/ 10 sec/ 20 sec/ 30 sec/ 40 sec/ 1Min/ 2 Min/ 4 Min

DOC Memory Address Range

There are 4 section option in the memory available to be selected. The choice: D8000-D9FFF, DA000-DBFFF, DC000-DDFFF and DE000-DFFFF.

4.8 Power Management Setup

The Power Management Setup allows you to configure you system to most effectively save energy while operating in a manner consistent with your own style of computer use.

■ Screen shot

CMOS Setup Utility – Copyright © 1984 –2001 Award Software
Power Management Setup

ACPI function	Enabled	Item Help
ACPI Suspend Type	S1(POS)	
Run VGABIOS if S3 Resume	Auto	Menu Level >
Power Management	User Define	
Video Off Method	DPMS	
Video Off In Suspend	Yes	
Suspend Type	Stop Grant	
MODEM Use IR0	3	
Suspend Mode	Disabled	
HDD Power Down	Disabled	
Soft-Off by PWR-BTTN	Instant-Off	
CPU THRM-Throttling	50.0%	
Wake-Up by PCI card	Enabled	
Power On by Ring	Enabled	
USB KB Wake-Up by PCI card	Enabled	
Resume by Alarm	Disabled	
Date(of Month) Alarm	0	
Time(hh:mm:ss) Alarm	0 0 0	
** Reload Global Timer Events **		
Primary IDE 0	Disabled	
Primary IDE 1	Disabled	
Secondary IDE 0	Disabled	
Secondary IDE 1	Disabled	
FDD,COM,LPT Port	Disabled	
PCI PIRQ(A-D) #	Disabled	
↑↓→← Move Enter: Select +/-/PU/PD: Value F10:Save ESC: Exit F1:General Help F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults		

ACPI Function

This item allows you to enable/disable the Advanced Configuration and Power Management (ACPI).

The choices : Enabled/Disabled.

ACPI Suspend Type

To decide which ACPI suspend mode to use.

The choices : S1(POS)/S3(STR)/S1&S3

Power Management

This category allows you to select the type (or degree) of power saving and is directly related to “HDD Power Down”, “Suspend Mode”.

There are three selections for Power Management, three of which have fixed mode settings.

Min. Power Saving	Minimum power management. Suspend Mode = 1 hr., and HDD Power Down = 15 min.
Max. Power Saving	Maximum power management. Suspend Mode = 1 min., and HDD Power Down = 1 min.
User Defined	Allows you to set each mode individually. When not disabled, Suspend Mode ranges from 1 min. to 1 hr. and HDD Power Down ranges from 1 min. to 15 min.

Video Off Method

This determines the manner in which the monitor is blanked.

V/H SYNC+Blank	This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.
Blank Screen	This option only writes blanks to the video buffer.
DPMS	Initial display power management signaling.

Video Off In Suspend

This allows user to enable/disable video off in Suspend Mode.

The choices : Yes/No

Suspend Type

Two options are available : Stop Grant and Power On Suspend.

Suspend Mode

When enabled and after the set time of system inactivity, all devices except the CPU will be shut off.

The choices : Disabled/1Min/2Min/4 Min /8 Min /12 Min /20 Min/40 Min/1 Hour.

HDD Power Down

When enabled and after the set time of system inactivity, the hard disk drive will be powered down while all other devices remain active.

The choices : Disabled/1Min/2Min/3 Min /4 Min /5 Min /6 Min /7 Min /8 Min /9 Min /10 Min /11 Min /12 Min /13 Min /14 Min /15 Min.

Soft-Off by PWR-BTTN

This item allows users to set the time to remove the power after the power button is pressed.

The choices : Instant-Off/Delay 4 Sec.

CPU THRM-Throttling

When the CPU temperature reaches the preset standard. The CPU usage will be reduced to a selected level to avoid overheating.

The choices : 87.5%/ 75.5%/ 62.5%/ 50.0%/ 37.5%/ 25.0%/ 12.5%

Wake-Up by PCI card

This option can be enabled to support Wake Up by on-board LAN.

The choices : Disabled/ Enabled

Power On by Ring

When select “Enabled”, a system that is at soft-off mode will be alert to Wake-On-Modem signal.

The choices : Enabled/Disabled

Resume by Alarm

This item allows users to enable/disable the resume by alarm function. When “Enabled” is selected, system using ATX power supply could be powered on if a customized time and day is approached.

The choices : Enabled/Disabled

Date(of Month) Alarm

When “Resume by Alarm” is enabled, this item could allow users to configure the date parameter of the timing dateline on which to power on the system.

The choices : 0 ~ 31

Time(hh:mm:ss) Alarm

When “Resume by Alarm” is enabled, this item could allow users to configure the time parameter of the timing dateline on which to power on the system.

The choices : hh (0~23), mm (0~59), ss (0 ~59)

Primary/Secondary IDE 0/1

This item is to configure IDE devices being monitored by system so as to keep system out of suspend mode if the associated device is busy.

The choices : Enabled/Disabled

FDD, COM, LPT Port

This item is to configure floppy device, COM ports, and parallel port being monitored by system so as to keep system out of suspend mode if the associated device is busy.

The choices : Enabled/Disabled

PCI PIRQ[A-D]#

This option can be used to detect PCI device activities. If there are activities, the system will go into sleep mode.

The choices : Enabled/Disabled

4.9 PnP/PCI Configuration Setup

This section describes configuring the PCI bus system. PCI, or **P**ersonal **C**omputer **I**nterconnect, is a system which allows I/O devices to operate at speeds nearing the speed the CPU itself uses when communicating with its own special components.

This section covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.

■ Screen shot

CMOS Setup Utility – Copyright © 1984-2001 Award Software
PnP/PCI Configurations

Reset Configuration Data	Disabled	Item Help
Resources Controlled By	Auto(ESCD)	-----
➤ IRQ Resources	Press Enter	Menu Level ➤
PCI/VGA Palette Snoop	Disabled	BIOS can automatically
Assign IRQ For VGA	Enabled	configure all the
INT PIN 1 Assignment	Auto	boot and Plug and Play
INT PIN 2 Assignment	Auto	compatible devices.
INT PIN 3 Assignment	Auto	If you choose Auto,
INT PIN 4 Assignment	Auto	you cannot select IRQ
INT PIN 5 Assignment	Auto	DMA and memory base
INT PIN 6 Assignment	Auto	address fields, since
INT PIN 7 Assignment	Auto	BIOS automatically
INT PIN 8 Assignment	Auto	assigns them
↑↓→←Move Enter: Select +/-/PU/PD: Value F10:Save ESC: Exit F1:General Help F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults		

Reset Configuration Data

Normally, you leave this field Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on card and the system reconfiguration has caused such a serious conflict that the operating system can not boot.

The choice: Enabled, Disabled .

Resource controlled by

The Award Plug and Play BIOS has the capacity to automatically configure all of the boot and Plug and Play compatible devices. However, this capability means absolutely nothing unless you are using a Plug and Play operating system such as Windows®95. If you set this field to “manual” choose specific resources by going into each of the sub menu that follows this field (a sub menu is preceded by a “>”).

The choice: Auto (ESCD), Manual.

IRQ Resources

When resources are controlled manually, assign each system interrupt a type, depending on the type of device using the interrupt.

The choice: Enter for more options

PCI/VGA Palette Snoop

Leave this field at Disabled.

The choices : Enabled/Disabled.

Assign IRQ For VGA

To enable VGA IRQ assignation by selecting enabled.

The choices : Enabled/Disabled.

INT PIN 1/2/3/4/5/6/7/8 Assignment

This BIOS option can assist users to assign IRQ numbers to particular slots. The IRQ number available are 3, 4, 5, 7, 9, 10, 11, 12, 14 and 15. Auto is the default value for each slot.

4.10 PC Health Status

■ **Screen shot**

CMOS Setup Utility – Copyright © 1984-2001 Award Software

PC Health Status

CPU Warning Temperature	Disabled	Item Help
Current System Temperature	38°C / 100°F	-----
Current CPU1 Temperature	43°C / 109°F	Menu Level >
Current CPU FAN Speed	43°C / 109°F	
Current Power FAN Speed	43°C / 109°F	
Current System FAN Speed	43°C / 109°F	
IN0(V)		
IN1(V)		
IN2(V)		
+ 5 V		
+12 V		
-12 V		
- 5 V		
VBAT(V)		
5VSB(V)		
CPU Throttle Temperature	Disabled	
↑↓→← Move Enter: Select +/-/PU/PD: Value F10:Save ESC: Exit F1:General Help F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults		

4.11 Frequency/Voltage Control

■ Screen shot

CMOS Setup Utility – Copyright © 1984-2000 Award Software
 Frequency/Voltage Control

CPU Clock Ratio	12 x	Item Help
Auto Detect PCI CLK	Enabled	-----
System Spectrum	Disabled	Menu Level >
↑↓→← Move Enter: Select +/-/PU/PD: Value F10:Save ESC: Exit F1:General Help F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults		

CPU Clock Ratio

This item allows you to select the CPU core/bus ratio. System auto detects the range.

Spread Spectrum

This item allows you to enable/disable the spread spectrum modulate

The choices : Enabled, Disabled

4.12 Default Menu

Selecting “Defaults” from the main menu shows you two options which are described below

Load Fail-Safe Defaults

When you press <Enter> on this item you get a confirmation dialog box with a message similar to:

Load Fail-Safe Defaults (Y/N) ? **N**

Pressing ‘Y’ loads the BIOS default values for the most stable, minimal-performance system operations.

Load Optimized Defaults

When you press <Enter> on this item you get a confirmation dialog box with a message similar to:

Load Optimized Defaults (Y/N) ? **N**

Pressing ‘Y’ loads the default values that are factory settings for optimal performance system operations.

4.13 Supervisor/User Password Setting

You can set either supervisor or user password, or both of them. The differences between are:

supervisor password : can enter and change the options of the setup menus.

user password : just can only enter but do not have the right to change the options of the setup menus. When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

ENTER PASSWORD

Type the password, up to eight characters in length, and press <Enter>. The password typed now will clear any previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable a password, just press <Enter> when you are prompted to enter the password. A message will confirm the password will be disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

PASSWORD DISABLED

When a password has been enabled, you will be prompted to enter it every time you try to enter Setup. This prevents an unauthorized person from changing any part of your system configuration.

Additionally, when a password is enabled, you can also require the BIOS to request a password every time your system is rebooted. This would prevent unauthorized use of your computer.

You determine when the password is required within the BIOS Features Setup Menu and its Security option (see Section 3). If the Security option is set to “System”, the password will be required both at boot and at entry to Setup. If set to “Setup”, prompting only occurs when trying to enter Setup.

4.14 Exiting Selection

Save & Exit Setup

Pressing <Enter> on this item asks for confirmation:

Save to CMOS and EXIT (Y/N)? **Y**

Pressing “Y” stores the selections made in the menus in CMOS – a special section of memory that stays on after you turn your system off. The next time you boot your computer, the BIOS configures your system according to the Setup selections stored in CMOS. After saving the values the system is restarted again.

Exit Without Saving

Pressing <Enter> on this item asks for confirmation:

Quit without saving (Y/N)? **Y**

This allows you to exit Setup without storing in CMOS any change. The previous selections remain in effect. This exits the Setup utility and restarts your computer.

4.15 POST Messages

During the Power On Self-Test (POST), if the BIOS detects an error requiring you to do something to fix, it will either sound a beep code or display a message. If a message is displayed, it will be accompanied by:

PRESS F1 TO CONTINUE, CTRL-ALT-ESC OR DEL TO ENTER SETUP

POST Beep

Currently there are two kinds of beep codes in BIOS. This code indicates that a video error has occurred and the BIOS cannot initialize the video screen to display any additional information. This beep code consists of a single long beep followed by two short beeps. The other code indicates that your DRAM error has occurred. This beep code consists of a single long beep repeatedly.

Error Messages

One or more of the following messages may be displayed if the BIOS detects an error during the POST. This list includes messages for both the ISA and the EISA BIOS.

CMOS BATTERY HAS FAILED

CMOS battery is no longer functional. It should be replaced.

CMOS CHECKSUM ERROR

Checksum of CMOS is incorrect. This can indicate that CMOS has become corrupt. This error may have been caused by a weak battery. Check the battery and replace if necessary.

DISK BOOT FAILURE, INSERT SYSTEM DISK AND PRESS ENTER

No boot device was found. This could mean that either a boot drive was not detected or the drive does not contain proper system boot files. Insert a system disk into Drive A: and press <Enter>. If you assumed the system would boot from the hard drive, make sure the controller is inserted correctly and all cables are properly attached. Also be sure the disk is formatted as a boot device. Then reboot the system.

DISKETTE DRIVES OR TYPES MISMATCH ERROR - RUN SETUP

Type of diskette drive installed in the system is different from the CMOS definition. Run Setup to reconfigure the drive type correctly.

DISPLAY SWITCH IS SET INCORRECTLY

Display switch on the motherboard can be set to either monochrome or color. This indicates the switch is set to a different setting than indicated in Setup. Determine which setting is correct, and then either turn off the system and change the jumper, or enter Setup and change the VIDEO selection.

DISPLAY TYPE HAS CHANGED SINCE LAST BOOT

Since last powering off the system, the display adapter has been changed. You must configure the system for the new display type.

EISA Configuration Checksum Error PLEASE RUN EISA CONFIGURATION UTILITY

The EISA non-volatile RAM checksum is incorrect or cannot correctly read the EISA slot. This can indicate either the EISA non-volatile memory has become corrupt or the slot has been configured incorrectly. Also be sure the card is installed firmly in the slot.

EISA Configuration Is Not Complete PLEASE RUN EISA CONFIGURATION UTILITY

The slot configuration information stored in the EISA non-volatile memory is incomplete.

Note: When either of these errors appear, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.

ERROR ENCOUNTERED INITIALIZING HARD DRIVE

Hard drive cannot be initialized. Be sure the adapter is installed correctly and all cables are correctly and firmly attached. Also be sure the correct hard drive type is selected in Setup.

ERROR INITIALIZING HARD DISK CONTROLLER

Cannot initialize controller. Make sure the cord is correctly and firmly installed in the bus. Be sure the correct hard drive type is selected in Setup. Also check to see if any jumper needs to be set correctly on the hard drive.

FLOPPY DISK CNTRLR ERROR OR NO CNTRLR PRESENT

Cannot find or initialize the floppy drive controller. make sure the controller is installed correctly and firmly. If there are no floppy drives installed, be sure the Diskette Drive selection in Setup is set to NONE.

Invalid EISA Configuration PLEASE RUN EISA CONFIGURATION UTILITY

The non-volatile memory containing EISA configuration information was programmed incorrectly or has become corrupt. Re-run EISA configuration utility to correctly program the memory.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.

KEYBOARD ERROR OR NO KEYBOARD PRESENT

Cannot initialize the keyboard. Make sure the keyboard is attached correctly and no keys are being pressed during the boot.

If you are purposely configuring the system without a keyboard, set the error halt condition in Setup to HALT ON ALL, BUT KEYBOARD. This will cause the BIOS to ignore the missing keyboard and continue the boot.

Memory Address Error at ...

Indicates a memory address error at a specific location. You can use this location along with the memory map for your system to find and replace the bad memory chips.

Memory parity Error at ...

Indicates a memory parity error at a specific location. You can use this location along with the memory map for your system to find and replace the bad memory chips.

MEMORY SIZE HAS CHANGED SINCE LAST BOOT

Memory has been added or removed since the last boot. In EISA mode use Configuration Utility to reconfigure the memory configuration. In ISA mode enter Setup and enter the new memory size in the memory fields.

Memory Verify Error at ...

Indicates an error verifying a value already written to memory. Use the location along with your system's memory map to locate the bad chip.

OFFENDING ADDRESS NOT FOUND

This message is used in conjunction with the I/O CHANNEL CHECK and RAM PARITY ERROR messages when the segment that has caused the problem cannot be isolated.

OFFENDING SEGMENT:

This message is used in conjunction with the I/O CHANNEL CHECK and RAM PARITY ERROR messages when the segment that has caused the problem has been isolated.

PRESS A KEY TO REBOOT

This will be displayed at the bottom screen when an error occurs that requires you to reboot. Press any key and the system will reboot.

PRESS F1 TO DISABLE NMI, F2 TO REBOOT

When BIOS detects a Non-maskable Interrupt condition during boot, this will allow you to disable the NMI and continue to boot, or you can reboot the system with the NMI enabled.

RAM PARITY ERROR - CHECKING FOR SEGMENT ...

Indicates a parity error in Random Access Memory.

Should Be Empty But EISA Board Found PLEASE RUN EISA CONFIGURATION UTILITY

A valid board ID was found in a slot that was configured as having no board ID.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

Should Have EISA Board But Not Found PLEASE RUN EISA CONFIGURATION UTILITY

The board installed is not responding to the ID request, or no board ID has been found in the indicated slot.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

Slot Not Empty

Indicates that a slot designated as empty by the EISA Configuration Utility actually contains a board.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

SYSTEM HALTED, (CTRL-ALT-DEL) TO REBOOT ...

Indicates the present boot attempt has been aborted and the system must be rebooted. Press and hold down the CTRL and ALT keys and press DEL.

Wrong Board In Slot PLEASE RUN EISA CONFIGURATION UTILITY

The board ID does not match the ID stored in the EISA non-volatile memory.

NOTE: When this error appears, the system will boot in ISA mode, which allows you to run the EISA Configuration Utility.
--

FLOPPY DISK(S) fail (80) Æ Unable to reset floppy subsystem.

FLOPPY DISK(S) fail (40) Æ Floppy Type mismatch.

Hard Disk(s) fail (80) Æ HDD reset failed

Hard Disk(s) fail (40) Æ HDD controller diagnostics failed.

Hard Disk(s) fail (20) Æ HDD initialization error.

Hard Disk(s) fail (10) Æ Unable to recalibrate fixed disk.

Hard Disk(s) fail (08) Æ Sector Verify failed.

Keyboard is locked out - Unlock the key.

Keyboard error or no keyboard present.

Cannot initialize the keyboard. Make sure the keyboard is attached correctly and no keys are being pressed during the boot.

BIOS ROM checksum error - System halted.

The checksum of ROM address F0000H-FFFFFH is bad.

Memory test fail.

BIOS reports the memory test fail if the onboard memory is tested error.

4.16 BIOS POST Check Point List

AWARDBIOS provides all IBM standard Power On Self Test (POST) routines as well as enhanced AWARDBIOS POST routines. The POST routines support CPU internal diagnostics. The POST checkpoint codes are accessible via the Manufacturing Test Port (I/O port 80h).

Whenever a recoverable error occurs during the POST, the system BIOS will display an error message describing the message and explaining the problem in detail so that the problem can be corrected.

During the POST, the BIOS signals a checkpoint by issuing one code to I/O address 80H. This code can be used to establish how far the BIOS has executed through the power-on sequence and what test is currently being performed. This is done to help troubleshoot faulty system board.

If the BIOS detects a terminal error condition, it will halt the POST process and attempt to display the checkpoint code written to port 80H. If the system hangs before the BIOS detects the terminal error, the value at port 80H will be the last

test performed. In this case, the terminal error cannot be displayed on the screen. The following POST checkpoint codes are valid for all AWARDBIOS products with a core BIOS date of 07/15/95 version 6.27 (Enhanced).

Code	Description
CFh	Test CMOS R/W functionality.
C0h	Early chipset initialization: -Disable shadow RAM -Disable L2 cache (socket 7 or below) -Program basic chipset registers
C1h	Detect memory -Auto-detection of DRAM size, type and ECC. -Auto-detection of L2 cache (socket 7 or below)
C3h	Expand compressed BIOS code to DRAM
C5h	Call chipset hook to copy BIOS back to E000 & F000 shadow RAM.
0h1	Expand the Xgroup codes locating in physical address 1000:0
02h	Reserved
03h	Initial Superio_Early_Init switch.
04h	Reserved
05h	1. Blank out screen 2. Clear CMOS error flag
06h	Reserved
07h	1. Clear 8042 interface 2. Initialize 8042 self-test

Code	Description
08h	<ol style="list-style-type: none"> 1. Test special keyboard controller for Winbond 977 series Super I/O chips. 2. Enable keyboard interface.
09h	Reserved
0Ah	Disable PS/2 mouse interface (optional). Auto detect ports for keyboard & mouse followed by a port & interface swap (optional). Reset keyboard for Winbond 977 series Super I/O chips.
0Bh	Reserved
0Ch	Reserved
0Dh	Reserved
0Eh	Test F000h segment shadow to see whether it is R/W-able or not. If test fails, keep beeping the speaker.
0Fh	Reserved
10h	Auto detect flash type to load appropriate flash R/W codes into the run time area in F000 for ESCD & DMI support.
11h	Reserved
12h	Use walking 1's algorithm to check out interface in CMOS circuitry. Also set real-time clock power status, and then check for override.
13h	Reserved
14h	Program chipset default values into chipset. Chipset default values are MODBINable by OEM customers.
15h	Reserved
16h	Initial Early_Init_Onboard_Generator switch.
17h	Reserved
18h	Detect CPU information including brand, SMI type (Cyrix or Intel) and CPU level (586 or 686).
19h	Reserved
1Ah	Reserved
1Bh	Initial interrupts vector table. If no special specified, all H/W interrupts are directed to SPURIOUS_INT_HDLR & S/W interrupts to SPURIOUS_soft_HDLR.
1Ch	Reserved
1Dh	Initial EARLY_PM_INIT switch.
1Eh	Reserved
1Fh	Load keyboard matrix (notebook platform)
20h	Reserved
21h	HPM initialization (notebook platform)
22h	Reserved
23h	<ol style="list-style-type: none"> 1. Check validity of RTC value: e.g. a value of 5Ah is an invalid value for RTC minute. 2. Load CMOS settings into BIOS stack. If CMOS checksum fails, use default value instead. 3. Prepare BIOS resource map for PCI & PnP use. If ESCD is valid, take into consideration of the ESCD's legacy information. 4. Onboard clock generator initialization. Disable respective clock resource to empty PCI & DIMM slots. 5. Early PCI initialization: <ul style="list-style-type: none"> -Enumerate PCI bus number -Assign memory & I/O resource -Search for a valid VGA device & VGA BIOS, and put it into C000:0.

Code	Description
24h	Reserved
25h	Reserved
26h	Reserved
27h	Initialize INT 09 buffer
28h	Reserved
29h	Program CPU internal MTRR (P6 & PII) for 0-640K memory address. Initialize the APIC for Pentium class CPU. Program early chipset according to CMOS setup. Example: onboard IDE controller. Measure CPU speed. Invoke video BIOS.
2Ah	Reserved
2Bh	Reserved
2Ch	Reserved
2Dh	Initialize multi-language. Put information on screen display, including Award title, CPU type, CPU speed
2Eh	Reserved
2Fh	Reserved
30h	Reserved
31h	Reserved
32h	Reserved
33h	Reset keyboard except Winbond 977 series Super I/O chips.
34h	Reserved
35h	Reserved
36h	Reserved
37h	Reserved
38h	Reserved
39h	Reserved
3Ah	Reserved
3Bh	Reserved
3Ch	Test 8254
3Dh	Reserved
3Eh	Test 8259 interrupt mask bits for channel 1.
3Fh	Reserved
40h	Test 8259 interrupt mask bits for channel 2.
41h	Reserved
42h	Reserved
43h	Test 8259 functionality.
44h	Reserved
45h	Reserved
46h	Reserved
47h	Initialize EISA slot
48h	Reserved
49h	1. Calculate total memory by testing the last double word of each 64K page. 2. Program writes allocation for AMD K5 CPU.
4Ah	Reserved
4Bh	Reserved
4Ch	Reserved
4Dh	Reserved
4Eh	1. Program MTRR of M1 CPU 2. Initialize L2 cache for P6 class CPU & program CPU with proper cacheable range.

Code	Description
	3. Initialize the APIC for P6 class CPU. 4. On MP platform, adjust the cacheable range to smaller one in case the cacheable ranges between each CPU are not identical.
4Fh	Reserved
50h	Initialize USB
51h	Reserved
52h	Test all memory (clear all extended memory to 0)
53h	Reserved
54h	Reserved
55h	Display number of processors (multi-processor platform)
56h	Reserved
57h	1. Display PnP logo 2. Early ISA PnP initialization -Assign CSN to every ISA PnP device.
58h	Reserved
59h	Initialize the combined Trend Anti-Virus code.
5Ah	Reserved
5Bh	(Optional Feature) Show message for entering AWDFLASH.EXE from FDD (optional)
5Ch	Reserved
5Dh	1. Initialize Init_Onboard_Super_IO switch. 2. Initialize Init_Onboard_AUDIO switch.
5Eh	Reserved
5Fh	Reserved
60h	Okay to enter Setup utility; i.e. not until this POST stage can users enter the CMOS setup utility.
61h	Reserved
62h	Reserved
63h	Reserved
64h	Reserved
65h	Initialize PS/2 Mouse
66h	Reserved
67h	Prepare memory size information for function call: INT 15h ax=E820h
68h	Reserved
69h	Turn on L2 cache
6Ah	Reserved
6Bh	Program chipset registers according to items described in Setup & Auto-configuration table.
6Ch	Reserved
6Dh	1. Assign resources to all ISA PnP devices. 2. Auto assign ports to onboard COM ports if the corresponding item in Setup is set to "AUTO".
6Eh	Reserved
6Fh	1. Initialize floppy controller 2. Set up floppy related fields in 40:hardware.
70h	Reserved
71h	Reserved
72h	Reserved

Code	Description
73h	(Optional Feature) Enter AWDFLASH.EXE if : -AWDFLASH is found in floppy drive. -ALT+F2 is pressed
74h	Reserved
75h	Detect & install all IDE devices: HDD, LS120, ZIP, CDROM.....
76h	Reserved
77h	Detect serial ports & parallel ports.
78h	Reserved
79h	Reserved
7Ah	Detect & install co-processor
7Bh	Reserved
7Ch	Reserved
7Dh	Reserved
7Eh	Reserved
7Fh	1. Switch back to text mode if full screen logo is supported. -If errors occur, report errors & wait for keys -If no errors occur or F1 key is pressed to continue: ♦Clear EPA or customization logo.
80h	Reserved
81h	Reserved
82h	1. Call chipset power management hook. 2. Recover the text font used by EPA logo (not for full screen logo) 3. If password is set, ask for password.
83h	Save all data in stack back to CMOS
84h	Initialize ISA PnP boot devices
85h	1. USB final Initialization 2. NET PC: Build SYSID structure 3. Switch screen back to text mode 4. Set up ACPI table at top of memory. 5. Invoke ISA adapter ROMs 6. Assign IRQs to PCI devices 7. Initialize APM 8. Clear noise of IRQs.
86h	Reserved
87h	Reserved
88h	Reserved
89h	Reserved
90h	Reserved
91h	Reserved
92h	Reserved
93h	Read HDD boot sector information for Trend Anti-Virus code
94h	1. Enable L2 cache 2. Program boot up speed 3. Chipset final initialization. 4. Power management final initialization 5. Clear screen & display summary table 6. Program K6 write allocation 7. Program P6 class write combining

Code	Description
95h	<ol style="list-style-type: none">1. Program daylight saving2. Update keyboard LED & typematic rate
96h	<ol style="list-style-type: none">1. Build MP table2. Build & update ESCD3. Set CMOS century to 20h or 19h4. Load CMOS time into DOS timer tick5. Build MSIRQ routing table.
FFh	Boot attempt (INT 19h)

4.17 BIOS Flash Utility

Utilize AWARD Flash BIOS programming utility to update on-board BIOS for the future new BIOS version. Please contact your technical window to get this utility if necessary.

NOTE : Remark or delete any installed Memory Management Utility (such as HIMEM.SYS, EMM386.EXE, QEMM.EXE, ..., etc.) in the CONFIG.SYS files before running Flash programming utility.

Chapter 5

5.1 ATX Power Setting

This part of the Quick Installation Guide provides you a few useful tips to quickly get your ROBO-8710VLA running without failure. As jumper configuration has been addressed in the earlier paragraphs, this section will basically focus on the **ATX power** setting.

Backplane

ROBO-8710VLA is a full-sized SBC, and therefore is able to run on any PICMG backplane, active or passive.

P4 Power connector

This P4 SBC requires power drawing from at least two connectors. The CPU supplementary power connector (J5) should be connected at all time for this P4 system to run properly. At its standalone mode, the single board computer will connect no peripheral device cards. 4-pin supplementary connector for CPU (J5) and the 4 pin connector (J13) must be connected. If the system's main power comes from a backplane, the CPU supplementary power connector (J5) should still be connected.

ATX power

ROBO-8710VLA is designed to support both AT and ATX powering. The following instruction demonstrates how the ATX function can be applied.

ROBO-8710VLA adapts its ATX power through its ATX power control connector (J11). This ATX power interface can be connected to a supported backplane. Such a backplane is required to have a 4-pin connector for feeding the ATX power to ROBO-8710VLA. An example is illustrated below:




Figure. 3 ATX power control connection on backplane

Please short both 3-5 and 4-6 pin of JP4 to enable its ATX function. Besides connecting the 4-pin ATX power control cable to J11. A TOGGLE SWITCH should be used to switch the ATX Power on/off for SBC. Usually the TOGGLE SWITCH is located on the chassis front panel. By pressing the switch button once, the power will be on, and press again to turn it off. It should be connected to J16.

The last thing to do before your ROBO-8710VLA system can be ATX powered is to connect 20-pin power cable of the ATX POWER to the backplane. By switching your ATX power on, the system goes into power standby. Clicking your ROBO-8710VLA ATX power button should successfully turn the system on.